

A2M - HW Features - LED Indicator

LED Indicator

Following LED indicators exists on AirID Mini

Color	Meaning
red	on while battery charging; off when battery charging is done
blue	on while bluetooth communication activities
green	on while smart card activities